



## Single Axis Gyroscope Fiber

Email:info@senofee.com / http://www.senofee.com

#### **General Description**

As a new type of all-solid-state gyroscope, fiber optic gyroscope has the advantages of fast start-up, wide measurement range and high reliability. FoG150 type single-axis low- and e-dium-precision fiber optic gyroscope can be applied to land positioning and orientation, vehicle north finder, airborne attitude, marine gyro compass, etc.Application requirements of edium and high precision inertial navigation system. This manual is only applicable to products, including performance indicators, technical conditions, overall dimensions and installation and use. Among them, the technical conditions include the environmental range, electrical performance, and physical characteristics of the product.

#### **Specifications**

Zero bias stability:≤0.3°/hr(1ơ) Measuring axis: Single-axis Power supply voltage range: 9-35v Anti-vibration performance: >2000g Store temperature : -55°C~+100°C Zero temperature drift (-40 ° C ~ 85 ° C): ± 0.005 °

#### **Applications**

1:Motionattitude control 3: Servo tracking 5: Automatic cargo truck 7: Oil drilling 9:Drone 11.Airborne attitude Random walk coefficient:≤0.01°/*hr* Measuring range: ±500° Output signal:RS422 output Wide temperature working: -40°C ~ +85°C

- 2:Damping of high speed train swing
- 4: Robot balance
- 6: Locking of the aiming system
- 8: Monitoring structural deformation
- 10:Building monitoring




#### **Performance Spectification**

Parameter	А	В	С		
Measuring range	-500°/S~+500°/S	-500°/S~+500°/S	-500°/S~+500°/S		
Zero bias stability	≤0.3°/hr(1σ)	≤0.2°/hr(1σ)	≤0.1°/hr(1σ)		
Zero Bias repeatability	≤0.3°/hr(1σ)	≤0.2°/hr(1σ)	≤0.1°/hr(1σ)		
Random walk coefficient	≤0.02°/√hr	≤0.02°/√hr	≤0.01°/√hr		
Scale factor nonlinearity	$\leq 100 \text{ppm}(1\sigma) \leq 50 \text{ppm}(1\sigma)$		≤50ppm(1σ)		
Scalefactor asymmetry	≤100ppm(1σ)	≤50ppm(1σ)	≤50ppm(1σ)		
Data refresh rate	200~2000	200~2000	200~2000		
Total temperature scale factor repeatability	≤1000	≤300	≤200		
Magnetic field sensitivity	-	-	-		
Baud rate(bps)	115200~921600				
Frequency bandwidth	≥200Hz				
Start time	15				
Working temperature	-40 ~ +60°C				
Storage temperature	-45~+80°C				
OutPut mode	RS422				
Connector	J30-15ZK				
Weight ( g )	130±10				

#### Sinusoidal sweep vibration

The gyroscope is fixed on the vibrating table through tooling according to the vibration direction, and the gyroscope performs sinusoidal scanning in 3 directions, corre sponding to the X-axis, Y-axis, and Z-axis directions. Vibration step: add excitation to the vibrating table, power up the gyroscope, warm up for a certain period of time (gyrostart time), test the gyroscope output value, about 5min; perform sinusoidal vibration. Vibration conditions: 20Hz-2000Hz, scan time 5min, amplitude 4.2g. During the vibration, record the gyroscope output.



Indicator requirements:

The fiber optic gyroscope has no resonance in the sine frequency sweeping range of 20HZ ~ 2000Hz;

Random vibration: the absolute value of the zero offset value in the vibration and the average value of the front and back zero offsets must be less than 0.5°/h.

#### Impact test conditions

Peak acceleration (g)	30			
Duration (ms)	10			
Number of impacts	3 times in each direction			
Waveform	Half sine wave			
Direction	Χ, Υ, Ζ			
Note: The interval between two impacts is not less than 1.5s				

During the impact, the product is in the energized state, and the product should be able to work normally after completing the mechanical impact. The zero change value before and after the impact is less than 0.3°/h.

#### Email:info@senofee.com / http://www.senofee.com

### Definition of output interfaces

Node number	Definition	Remark	colour
1	T+	X gyroscope output signal+	Yellow
2	T-	X gyroscope output signal-	Orange
3	R+	R gyroscope output signal+	Blue
4	R-	R gyroscope output signal-	Green
5、13	+5V	+5V power input	Red
6、7	$\pm$ 5VGND	GND	Black



ITEM NO: FOG150

# Single Axis Gyroscope Fiber

Email:info@senofee.com / http://www.senofee.com